#### **Door Prep for Small Rosettes**

These instructions MUST be used for all rosettes with diameters less than 2.5'' and doors thicker than 1-3/4''. Optional for door thickness of 1-3/8'' to 1-3/4'' with a 5/8'' face bore.



NOTE: We recommend the use of the Baldwin Trim Aligning Tool to ensure precise alignment of the latch and trim.

#### Installing Passage Locks with Small Rosettes

These instructions MUST be used for all rosettes with diameters less than 2.5'' and a door thickness of 1-3/8'' to 1-3/4'' with a 5/8'' face bore.



#### **Installing Privacy Locks with Small Rosettes**

These instructions MUST be used for all rosettes with diameters less than 2.5'' and a door thickness of 1-3/8'' to 1-3/4'' with a 5/8'' face bore.



### Door Prep for Large Rosettes





NOTE: We recommend the use of the Baldwin Trim Aligning Tool to ensure precise alignment of the latch and trim.

### Installing Passage or Privacy Locks with Large Rosettes

These instructions may be used for rosettes with diameters greater than 2.5'' and a door thickness of 1-3/8'' to 1-3/4'' with a 2-1/8'' face bore.

#### OUTSIDE **Adapter Installation Process** ALIGNMENT ADAPTER BUSHING 1. Use instructions and template to install latch. 2. Position the adapters so the #10 machine screws are inserted from the inside face of the INSIDE door. ADAPTER 3. Loosely thread the #10 machine screws through the inside adapter into the outside ALIGNMENT adapter. -BUSHING 4. Insert the spindle into the latch. (INSTALLED) 5. Insert the alignment bushings into both $\odot$ adapters. 6. Fully tighten the #10 machine screws. 7. Remove the alignment bushings and discard. -SPINDLE 8. Attach roses to adapters and install knobs or levers. LATCH-#10 MACHINE SCREWS