

**BALDWIN INSTALLATION TEMPLATE GUIDE CHART
FOR RESIDENTIAL AND UL LISTED MORTISE LOCKS AND TRIM**

Read down left-hand column to find your Lock Number. Read across the page to determine the hole pattern of your Lock Trim. Mark holes indicated on yellow Template enclosed to be used to transfer the hole pattern to the door.

6000 SERIES LOCKS ² <i>2-3/4" B/S KNOB & LEVER FUNCTION</i> MORTISE POCKET DIM. <i>15/16" W. X 4-1/8" D.</i>	6300 SERIES LOCKS ² <i>2-1/2" B/S KNOB & LEVER FUNCTION</i> MORTISE POCKET DIM. <i>7/8" W. X 3-5/8" D.</i>	6800 SERIES LOCKS <i>2" B/S LEVER FUNCTION</i> MORTISE POCKET DIM. <i>13/16" W. X 3-1/4" D.</i>	6800 SERIES LOCKS <i>1-1/2" B/S LEVER FUNCTION</i> MORTISE POCKET DIM. <i>13/16" W. X 2-3/4" D.</i>	DOOR PREP	TRIM				TRIM 5	TRIM 5	TRIM 5	TRIM 5	TRIM 5	TRIM 5	TRIM 5
					6541 6546 6547 6548 6550 6551 6552 6553 6554	6555 6558 6561 6580 6910 6915 6916 6917 6918	6920 6921 6922 6923 6924 6927 6928 6929 6932	6933 6935 6938 6939 6940 6942 6945 6951 6961 6962	6543 ⁴ 6556 ⁴ 6572 ⁴ 6963 6981 6982 6984	6520 6540 ⁴ 6557 ⁴ 6559 6563 ⁴ 6944 6952 M502	M504 M512 M514 M516 6921 6920 6616 6615	6562 ^{3,5} 6564 ⁴ 6565 ⁴ 6931 6999	6515 6516 6526 6549 6560 6567 6573 6937 6948 6950 6966	6946 6977	6571
6001	6301	6802	6800	INSIDE	3-4										
				OUTSIDE	2-4										
6075	6375			INSIDE	3-4										
				OUTSIDE	2-4										
6077				INSIDE	3-4										
				OUTSIDE	2-4										
6080				INSIDE	2-4										
				OUTSIDE	2-4										
6005	6305	6807	6805	INSIDE	2-4										
				OUTSIDE	2-4										
6010	6310	6812	6810	INSIDE	3-4										
				OUTSIDE	2-4										
6091				INSIDE	3-4										
				OUTSIDE	2-4										
6096				INSIDE	3-4										
				OUTSIDE	2-3-4										
6060				INSIDE	4										
				OUTSIDE	2-4										
6130				INSIDE	4										
				OUTSIDE	2-4										
6065				INSIDE	4										
				OUTSIDE	2-4										
6085				INSIDE	2-4										
				OUTSIDE	2-4										
6070				INSIDE	3-4										
				OUTSIDE	2-4										
6110	6318	6857	6855	INSIDE	4										
				OUTSIDE	4										
6100	6315	6847	6845	INSIDE	3-4										
				OUTSIDE	3-4										
6055				INSIDE	3-4										
				OUTSIDE	3-4										
6150			6850	INSIDE	NONE ¹										
				OUTSIDE	2 ¹										
6160			6860	INSIDE	3 ¹										
				OUTSIDE	2 ¹										
6170			6870	INSIDE	2 ¹										
				OUTSIDE	2 ¹										
6020	6320	6832	6830	INSIDE		3-4-6-9	3-4-6-13	3-4-6-8	3-4-6-10	3-4-6-14	3-4-6-7	3-4-6-11	3-4-6-12		
				OUTSIDE		2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6
6021	6321			INSIDE		3-4-6-9	3-4-6-13	3-4-6-8	3-4-6-10	3-4-6-14	3-4-6-7	3-4-6-11	3-4-6-12		
				OUTSIDE		2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6
6022	6322	6837	6835	INSIDE		2-4-6-9	2-4-6-13	2-4-6-8	2-4-6-10	2-4-6-14	2-4-6-7	2-4-6-11	2-4-6-12		
				OUTSIDE		2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6	2-4-5-6
6025	6325			INSIDE		2-5-9	2-5-13	2-5-8	2-5-10	2-5-14	2-5-7	2-5-11	2-5-12		
				OUTSIDE		2-5-6	2-5-6	2-5-6	2-5-6	2-5-6	2-5-6	2-5-6	2-5-6	2-5-6	2-5-6
6030				INSIDE		2-5-9	2-5-13	2-5-8	2-5-10	2-5-14	2-5-7	2-5-11	2-5-12		
				OUTSIDE		2-5-6	2-5-6	2-5-6	2-5-6	2-5-6	2-5-6	2-5-6	2-5-6	2-5-6	2-5-6
6066				INSIDE		4-6-9	4-6-13	4-6-8	4-6-10	4-6-14	4-6-7	4-6-11	4-6-12		
				OUTSIDE		2-4-5	2-4-5	2-4-5	2-4-5	2-4-5	2-4-5	2-4-5	2-4-5	2-4-5	2-4-5
6051				INSIDE	4										
				OUTSIDE	2-4										
6053				INSIDE	4										
				OUTSIDE	2-4										
	8550			INSIDE	NONE ¹										
				OUTSIDE	2A ¹										
	8555			INSIDE	2A ¹										
				OUTSIDE	2A ¹										
	8560			INSIDE	3B ¹										
				OUTSIDE	2A ¹										

¹ No trim required for these locks.

² 6000 & 6300 Series are UL listed.

³ For trims noted, drill hole 1.

⁴ For lower pull holes, drill 1/2" diameter x 1/4" deep hole on outside.

⁵ For hole 5, drill a 1" wide x .500" deep, oblong counterbore on outside. For hole 6, drill .312" diameter escutcheon hole on inside except for trims indicated by Note 6.

⁶ For hole 6, drill .500" diameter escutcheon hole (not .312") on inside.

See reverse side for Back-to-Back Handlesets.

**BALDWIN INSTALLATION TEMPLATE GUIDE CHART
BACK-TO-BACK HANDLESETS**

Read down left-hand column to find your Lock Number. Read across the page to determine the hole pattern of your Lock Trim. Mark holes indicated on yellow Template enclosed to be used to transfer the hole pattern to the door.

			5.75	6.0	6.5	7.0	8
2-3/4" B/S KNOB & LEVER FUNCTION	2-1/2" B/S KNOB & LEVER FUNCTION	DOOR PREP	TRIM 6608 6690	TRIM 6627 6635	TRIM 6553 6602 6621 6628 6956	TRIM 6605 6607 6619 6620 6622	TRIM 6603 6641 6652
6025	6325	INSIDE	2, 5, 6, 8	2, 5, 6, 9	2, 5, 6, 10	2, 5, 6, 11	2, 5, 6, 12
		OUTSIDE					
6030		INSIDE	2, 5, 6, 8	2, 5, 6, 9	2, 5, 6, 10	2, 5, 6, 11	2, 5, 6, 12
		OUTSIDE					