

# FLOOR MIX / MUD

Superior Floor Mix is a factory-prepared mixture of Portland cement and graded sand designed to mix with water to make semi-dry conventional floor mortar beds.

## Key Features

- Used for interior traditional mortar beds
- Ideal where traditional mortar bed is required for small shower pans
- Exceeds 5000 psi compressive strength workability

## Installation

**Packaging:** 80lb bags

**Colors:** Grey

**Mixing Ratio:** 1 gallon per 80lb

**Coverage:** Approx. 6 - 8 sq. ft. at 1 in. thickness  
Approx. 3 - 4 sq. ft. at 2 in thickness  
Approx. 3 -6 sq ft. building a shower

**Cure Time:** 24 - 72 hours

**Shelf Life:** 15 months. Store in a cool, dry location

## Related Products

- Superior Flexible Grout Admixture

## Installation Tips

- Do not breathe dusts; use only outdoors or in well-ventilated areas
- Avoid contact with skin. If contact occurs, wash thoroughly with soap and water
- Wear protective gloves, protective clothing, eye protection, and face protection
- For superior results, mix 1 quart of Admixture with 3 quarts of water per 80lb bag

## Steps to Mix Mud

- ① Mix in a large pail, wheelbarrow, or mortar box and gradually add water or admixture, Mix approximately 1 gallon per 80lb bag.
- ② Mix with a shovel or rake to an even consistency.
- ③ When Floor Mix can be packed into a ball without crumbling apart, the correct consistency has been reached.
- ④ Refer to ANSI 109.1 for details on mortar bed installations and the TCNA Installation Handbook for mortar-bed standards.
- ⑤ Allow the mortar to fully cure approximately 24 - 72 hours.

