

PRO-SHIELD BACKER BOARD

Superior Pro-Shield board is an XPS foam panel manufactured to offer builders and tile contractors a strong, lightweight, waterproof and vapor-resistant tile base for wet areas. Pro-Shield is reinforced with an alkali-resistant fiber mesh offering exceptional bonding strength.

Key Features

- Lightweight, waterproof and vapor-resistant
- Offers a wide variety of applications, including those that are exposed to high moisture
- Exceptional bonding strength due to manufactured composition

Installation

Sizes: 3' x 5' x 0.5"

Coverage: 15 sq. ft.

Related Products

- Screws and Washers
- Pro-Shield I/O Corners
- Pro-Shield Shower Curb
- Pro-Shield Shower Pan
- Pro-Shield Board
- Pro-Shield Center Drain
- Pro-Shield Pipe Collar 3/4"
- Pro-Shield Mix Valve Collar 4 1/2"
- Seal Tape

Installation Tips

- Wear suitable protective clothing and gloves
- All surfaces must be structurally sound and free of contaminants before
- Refrain from using if rain or moisture is expected within 24 hours of application
- Store flat and in a dry location; protect from direct sunlight

Steps to Install Backer Board

- ① Surfaces should be dry and free of adhesives, paint, wax, dirt, grease and any other foreign materials that may inhibit bonding.
- ② Position backer board on the wall; use shims to raise the board 1/4" from the base of the shower pan to help prevent water from seeping into the thinset. Take accurate measurements of plumbing fixtures and transfer them to backer board to get desired cuts.
- ③ Secure the board with provided screws and washers. Tape all seams with fiberglass mesh tape.
- ④ Flat trowel modified thinset over mesh tape.
- ⑤ Check to make sure you achieve full coverage. Allow 24 hours for thinset to cure.

