

PRO-SHIELD MEMBRANE

Superior Pro-Shield Membrane is a premium waterproofing system designed to protect moisture-sensitive building materials and control mold growth.

Key Features

- Lightweight membrane
- For use under tile and stone surfaces in showers and wet areas
- Suitable for chemical resistant flooring
- Meets or exceeds ANSI 118.10

Installation

- Sizes:** 3' x 3" x 33"
3' x 3" x 98'5"
- Coverage:** 108 sq. ft. and 323 sq. ft.
- Color:** Grey
- Thickness:** Approx. 0.5 mm
- Roll Width:** 3.25 ft.
- Roll Length:** 33 ft.
98.5 ft.

Related Products

- Screws and Washers
- Pro-Shield I/O Corners
- Pro-Shield Shower Curb
- Pro-Shield Shower Pan
- Pro-Shield Board
- Pro-Shield Center Drain
- Pro-Shield Pipe Collar 3/4"
- Pro-Shield Mix Valve Collar 4 1/2"
- Seal Tape
- Thinset
- Trowel

Installation Tips

- Wear suitable protective clothing and gloves
- All surfaces must be structurally sound and free of contaminants before
- Refrain from using if rain or moisture is expected within 24 hours of application
- Store flat and in a dry location; protect from direct sunlight

Steps to Install Membrane

- ① Surfaces should be dry and free of adhesives, paint, wax, dirt, grease and any other foreign materials that may inhibit bonding.
- ② Using a 1/4" x 3/16" V-notch trowel, apply a thin bed of Superior ANSI 118.4 or 118.15 thinset to the substrate.
- ③ Seal all transitional areas between the wall and floor with Superior Pro-Shield accessory products.
- ④ Embed the entire surface of the board into freshly combed thinset with even pressure working from center outwards to force out any air pockets and collapse ridges.
- ⑤ Make sure to compress all trowel ridges for full coverage. Check to make sure you achieve full coverage. Allow 24 hours for thinset to cure.

