

PRO-SHIELD SHOWER PANS

Superior Pro-Shield Shower Pans are pre-sloped, waterproof shower pans designed to make tiled shower installations quick and easier than traditional mud-based shower installations.

Key Features

- Can be easily cut to size
- Offers a quick, easy and secure installation
- Built-in stainless steel drain assembly included
- Lightweight and waterproof shower pan intended for use with the Pro-Level Self-Leveling System
- Meets or exceeds ANSI 118.10 and 118.12

Installation

Sizes: 36" x 60"
48" x 48"

Coverage: 15 sq. ft. and 16 sq. ft.

Related Products

- Stainless Steel Square Drain
- Pro-Shield Shower Curb
- Pro-Level

Installation Tips

- Wear suitable protective clothing, eye goggles, gloves and dust mask as needed
- All surfaces must be structurally sound and free of contaminants before
- Refrain from using if rain or moisture is expected within 24 hours of application
- Store flat and in a dry location; protect from direct sunlight

Steps to Install Shower Pan

- ① Surfaces should be dry and free of any foreign materials. Ensure floor is level on all 4 sides of the drain. Remove protective cap from shower board and discard. Add the slip fit adapter to the back side of the board and set aside until step 4.
- ② Remove screws holding together the drain component and place aside for later use. Apply a thick bead of sealant around circle of drain, approximately 1/2" from the center of the drain.
- ③ Add metal connector piece and press it into the sealant. Line up the holes for screws and insert screws; do not tighten completely.
- ④ Using a 1/4" by 3/8" trowel and fill the area of the shower pan with straight, even thinset; repeat this process on the back side of the backer board.
- ⑤ Lower board into place aligning the drain connector first; then pack the pan firmly down to the floor.

