



**BALDWIN**

ESTATE™




**Installation Guide**  
Guía de instalación  
Guide d'installationbaldwinhardware.com  
800.566.1986

49506 / 01 Door Knocker 0106

**Tools Needed**  
Herramientas necesarias  
Outils nécessaires**1** Center template on EXTERIOR side of door. Ensure template is level, and mark holes.

Centre la plantilla en la parte EXTERIOR de la puerta. Asegúrese de que la plantilla se encuentre nivelada y marque los orificios.

Centrer le gabarit sur la face EXTERIEURE de la porte. Assurez vous que le gabarit est bien aligné et marquez les trous.

**2****3****Template**Plantilla  
Gabarit