Sunbeam®

Pets

Lighted nail trimmer

fast, gentle & stress free




INSTRUCTION MANUAL

FOR PETS WITH LONG HAIR

It is very important to **KEEP YOUR PET'S HAIR OUT OF THE WAY** – it may be best to put a stocking or sock over the paw, foot and leg of the pet and isolate the nail. Push the nail through an opening at the tip of the sock to trim the nails.

Keep the Hair Away From the Tool



HOW TO CLEAN

- Ensure nail trimmer is OFF and remove batteries.
- Never clean nail trimmer or replace bands with motor ON.
- Wipe nail trimmer with a damp cloth.
- Never use nail trimmer with water.
- Remove Safety Guard and wipe debris with a damp cloth.

NOTES

- This product is recommended to be used with the Safety Guard in place at all times.
- This product is intended to be used as a pet nail trimmer only.

SAFETY TIPS

Before trimming your pets nails

You should **secure your pet before nail trimming.** It may be helpful to have another person help you restrain and comfort your pet. The operator should have both hands available for trimming the pet's nails.

Rub their paws with your hands and allow them to get used to the touch.

Introduce the nail trimmer to your pet with it in the OFF position.


Acclimate your pet to the nail trimmer with it ON while giving praise and treats.

After a few rounds of introduction, your pet should be on its way to a **safe** and **healthy groom.**

Remember – you are in charge. The more assertive you are the more comfortable your pet will become.

Be patient with your pet. Do not use nail trimmer until your pet is completely comfortable.

YOUR LIGHTED NAIL TRIMMER PARTS



UNDERSTANDING BANDS

Grinding Drum – For use with Grinding Bands.

Durable Medium Sanding Band – Grinds nails down quickly.

Durable Fine Sanding Band – Smooths rough or sharp edges, leaves a super smooth finish.

For Replacement Bands call 1-866-537-2249

GET THE LIGHTED NAIL TRIMMER READY

1. Open battery compartment door and install four 1.5V 'AA' batteries.
2. Press the Collet Lock Button and turn the Collet to open.
3. Insert grinding band into the Collet.
4. Hold the Collet Lock Button and turn the Collet to close and secure band.
5. Test to make sure the band is secure.
6. Place the Safety Guard on the trimmer by screwing on and securing tightly.
   NOTE: Using the Lighted Nail Trimmer without the Safety Guard can cause injury or damage to unprotected areas.

STOP


Always use the Lighted Nail Trimmer in position ①
first then change to position ② only if necessary

TRIM PETS NAILS

1 Always start in position ① (speed). Hold the unit near the pet for a few seconds before filing to ensure the pet's comfort.


Take the pets paw and gently squeeze the nail between the thumb and pointer finger to extract nail.

(See back for tips on Long Hair Breeds.)




2 Insert a nail into the Safety Guard opening that is best for your pet's nail size.

Begin filing each nail, no more than, 2-4 seconds. NEVER trim one nail completely. Alternate between each nail.




3 Look at the nail each time you file to ensure you are taking off layer by layer.


Work the Lighted Nail Trimmer from the bottom of the nail to the top – in a slow methodical motion. This will round off the nail and leave a smooth finish.



4. Trim around sides of nails to remove sharp edges.



5. The lighted feature of the Sunbeam® Lighted Nail Trimmer helps make seeing the quick easier providing a safer nail trimming experience for you and your pet.



TIP

Properly introducing the Lighted Nail Trimmer to your pet will ensure a more comfortable experience for both you and your pet.

1 YEAR WARRANTY

In the U.S.A. and Canada

If you have any question regarding this warranty or would like to obtain warranty service, please call 1-866-537-2249 and a convenient service center address will be provided to you.

Sunbeam® Products, Inc. doing business as Jarden Consumer Solutions, or if in Canada, Sunbeam® Corporation (Canada) Limited doing business as Jarden Consumer Solutions (collectively "JCS") warrants that for a period of one year from the date of purchase, this product will be free from defects in material and workmanship. JCS, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty.

DO NOT attempt to repair or adjust any electrical or mechanical functions on this product. Doing so will void this warranty.

This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. JCS dealers, service centers, or retail stores selling JCS products do not have the right to alter, modify or any way change the terms and conditions of this warranty. This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than JCS or an authorized Sunbeam® service center. Further, the warranty does not cover: Acts of God, such as fire, flood, hurricanes and tornadoes.

What are the limits on Sunbeam's Liability?

JCS shall not be liable for any incidental or consequential damages caused by the breach of any express, implied or statutory warranty or condition. Except to the extent prohibited by applicable law, any implied warranty or condition of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty. JCS disclaims all other warranties, conditions or representations, express, implied, statutory or otherwise. JCS shall not be liable for any damages of any kind resulting from the purchase, use or misuse of, or inability to use the product including incidental, special, consequential or similar damages or loss of profits, or for any breach of contract, fundamental or otherwise, or for any claim brought against purchaser by any other party.

Some provinces, states or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from province to province, state to state or jurisdiction to jurisdiction.

In the U.S.A., this warranty is offered by Sunbeam® Products, Inc. doing business as Jarden Consumer Solutions located in Boca Raton, Florida 33431.

In Canada, this warranty is offered by Sunbeam® Corporation (Canada) Limited, doing business as Jarden Consumer Solutions located at 20 B Hereford Street, Brampton, Ontario L6Y 0M1.

PLEASE DO NOT RETURN THIS PRODUCT TO ANY OF THESE ADDRESSES OR TO THE PLACE OF PURCHASE.

GO ONLINE NOW

Receive a FREE GIFT OR PROMO CODE* at wwww.sunbeampets.com/S&MPCLG201.

It's our "thanks" to you for being a Sunbeam® Pets brand customer.

You will also get access to special sale items and promotions on a full assortment of Sunbeam® Pets branded products

Hurry & Sign-up Today!

***While supplies last; subject to availability.**

www.sunbeampet.com
1-866-537-2249

© 2013 Sunbeam Products, Inc. doing business as Jarden Consumer Solutions.
All rights reserved. Distributed by Sunbeam® Products, Inc. doing business as Jarden Consumer Solutions, Boca Raton, Florida 33431.

Printed in China Model #: 078129-700 SPR-060613-366 PN 156729