
baby jogger®

deluxe bassinet 2
couchette deluxe 2

CITY SELECT® 2

SUMMIT™ X3
















babyjogger.com
babyjogger.ca
babyjogger.co.nz


ASSEMBLY INSTRUCTIONS
INSTRUCTIONS POUR L'ASSEMBLAGE


©2026 NWL0001297853N 4/26


FOR SPANISH: Visit www.babyjogger.com for an instruction sheet.
PARA ESPAÑOL: Visite www.babyjogger.com para obtener una hoja de instrucciones.





CLICK
CLIC
CLICK
CLIC







A
B
C








11






CLICK
CLIC



12
CLICK
CLIC



13


14


15


16


17


18

⚠ WARNING

Failure to follow these warnings and the instructions could result in death or serious injury.

SUFFOCATION HAZARD: Babies have suffocated:
- on pillows, comforters, and extra padding
- in gaps between a wrong-size mattress, or extra padding and product sides

• NEVER add soft bedding or padding.
• Use ONLY mattress pad provided by Baby Jogger.
- Bassinet can roll over on soft surfaces and suffocate child.
• NEVER place bassinet on beds, sofas, or other soft surfaces.

READ ALL INSTRUCTIONS BEFORE USE OF THE INFANT CARRIER. KEEP INSTRUCTIONS FOR FUTURE USE.

• Always use the level of supervision necessary for the continued safety of your child when used as a bassinet on floor.
• DO NOT leave child unattended when used on stroller.

FALL HAZARD: To help prevent falls,
  • Do not use this product when the infant begins to rollover or has reached 9 kg (20 lb), whichever comes first.
  • Child's activity can move bassinet. Always use product on the floor. NEVER place bassinet on a stand, counter tops, tables, or any other elevated surface.
  • Always check that the bassinet is securely locked on the stroller by pulling upwards on the bassinet bed.
• NEVER use this bassinet as a means to transport an infant in a motor vehicle.
• DO NOT use this bassinet if you cannot exactly follow the instructions that come with it.
• DO NOT use this bassinet for a child who can roll over or who has reached 9 kg (20 lb).
• Do not place any cord, strap or similar item in or near this bassinet that could become wrapped around a child's neck.
• DO NOT place this bassinet near a window or patio door where a child could reach the cord of a blind or curtain and be strangled.
• Check this bassinet regularly before using it, and do not use it if any part is loose or missing or if there are any signs of damage. Do not substitute parts. Contact the manufacturer if replacement parts or additional instructions are needed.
• Children can suffocate on soft bedding. Do not place pillows, comforters or soft mattresses in this bassinet.
• This bassinet includes a 25 mm (1") mattress. Use only the mattress supplied by the manufacturer with this bassinet. Do not add an additional mattress to this bassinet.
• Use only the mattress cover included with this product. Do not use a sheet with the mattress pad.
• ALWAYS use mattress pad.
• This bassinet is suitable only for a child who cannot roll over or who has not yet reached 9 kg (20 lb). Maximum height of the child: 66 cm (26"). Excess weight may cause a hazardous, unstable condition to exist.

STRANGULATION HAZARD:
  - Strings and cords can cause strangulation!
  • Keep strings and cords away from child.
  • NEVER place items with a string around a child's neck, such as hood strings or pacifier cords. NEVER suspend strings over a product or attach strings to toys.
• DO NOT use if any part of bassinet is broken, torn, or missing.
• Do not use bassinet near open fire and other sources of strong heat, such as electric bar fires, gas fires, etc., in the near vicinity of the bassinet.
• Do not let other children play unattended near the bassinet.
• Use only replacement parts supplied or approved by the manufacturer.
• Product can be used on the stroller as a bassinet and to carry child.
• Always place baby on back to sleep to reduce the risk of SIDS and suffocation.
• Ensure that the sides of this bassinet are properly latched or locked in the appropriate position before placing a child in it.

UNPACK

1 After unboxing the bassinet, raise the canopy until it clicks into place, then undo the four fastening strips around the canopy.
2 Then remove the mattress, and undo the two fastening strips around the bassinet canopy mounts to remove the liner.
3 Pull black straps to slide metal adjustment bars until locked against the stoppers on the base to stabilize the walls of the bassinet body. Reattach liner and insert mattress.

FOOT COVER

4 To attach the foot cover, place the foot cover over the bassinet frame.
5 Attach the fastening strips on either side of the bassinet body.
6 On each side of the foot cover, thread the snap through the loop and close the snaps together to secure the foot cover to the bassinet frame.
7 You may also fold the top of the foot cover down and secure it using the lower loops.

CANOPY

8 Raise the canopy until it clicks into position B. Continue to raise the canopy to position A by pressing the buttons on either side of the canopy hinge.

⚠WARNING: Before carrying or lifting, make sure that the canopy is locked into position A.
NOTE: The canopy has 2 locked positions. Push and pull the handle to make sure the canopy is in a locked position. The canopy can be in any position when used in the stroller.

9 To lower the canopy, press the buttons on either side of the canopy hinge then lower the canopy.
10 To use the canopy window, unzip the canopy zipper. Then roll the shade up towards the top.

MOUNTING ADAPTERS

11 If you have a City Select 2 stroller, skip to step #12. Summit X3 Mounting Bracket Adapters for Summit X3 strollers: If you have a canopy already attached, remove the canopy by pressing the release buttons on either side of the stroller and pulling upward. Insert adapters into accessory mounting brackets on stroller.
NOTE: Left and right are determined by standing in front of and facing the stroller.

ATTACH TO STROLLER

12 Align the black attachment brackets of the deluxe bassinet 2 with the stroller Attachment Brackets. **The bassinet body can only be attached rear facing.** Firmly press down on the bassinet until you hear it click into place. Gently pull up on the bassinet to ensure it is locked in place.
13 To remove the bassinet body from the stroller: Press release button on each attachment bracket and pull upward to remove.

REMOVING THE INNER FABRIC

14 Unzip the canopy from the handle.
15 Undo the four fastening strips around the canopy. then remove the canopy fabric.
16 Undo the two fastening strips around the bassinet canopy mounts to remove the liner.

STORAGE

17 To collapse bassinet body for storage: Remove mattress and liner. Press release tabs and pull black straps to slide metal adjustment bars towards the middle. Flatten for storage.
18 When carrying with a child, always hold pram by the hand holds on sides of pram.

CARE AND MAINTENANCE

- Refer to your care tag for wash instructions:
  - Wipe clean using a damp cloth.
  - Hand wash in cold water with mild soap.
  - Machine wash separate in cold water, delicate cycle.
- Do not bleach.
- Do not tumble dry.
- Do not iron.
- Do not dry clean.
- Lay flat to dry.
- Remove mattress foam before washing mattress cover.

FR

⚠ MISE EN GARDE

Ne pas se conformer à toutes ces mises en garde et directives peut causer la mort ou des blessures graves.

DANGER DE SUFFOCATION : des bébés se sont déjà étouffés :

- Sur les oreillers, les couettes et les surmatelas
- Entre un matelas de taille inadéquate ou un surmatelas et les côtés du produit

• N'ajoutez JAMAIS de literie ou de surmatelas.

• Utilisez SEULEMENT le protège-matelas fourni par Baby Jogger.

- Cette couchette peut rouler sur les surfaces moelleuses causant la suffocation de l'enfant.

• NE JAMAIS placer cette couchette sur un lit, sofa ou toute autre surface moelleuse.

LIRE TOUTES LES DIRECTIVES AVANT D'UTILISER CE PORTE-BÉBÉ.
CONSERVER CES INSTRUCTIONS POUR UTILISATION FUTURE.

• Toujours assurer le niveau de supervision nécessaire pour assurer la sécurité continue de l'enfant lors de l'utilisation comme couchette au sol.

• NE PAS laisser l'enfant sans surveillance lors de l'utilisation avec la poussette.

RISQUE DE CHUTE : Afin de prévenir les chutes,

• Ne pas utiliser ce produit lorsque l'enfant commence à se retourner ou qu'il atteint 9 kg (20 lb), la première des deux situations prévalant.

• Les mouvements de l'enfant peuvent faire bouger la couchette. Toujours utiliser le produit sur le sol. NE JAMAIS placer cette couchette sur un support, comptoir, une table ou toute autre surface surélevée.

• Toujours vérifier que la couchette est solidement verrouillée sur la poussette en tirant l'assiette de la couchette vers le haut.

• NE JAMAIS utiliser cette couchette pour transporter un bébé dans un véhicule motorisé.

• NE PAS utiliser cette couchette s'il est impossible de suivre à la lettre les directives qui l'accompagnent.

• NE PAS utiliser cette couchette pour un enfant qui peut se retourner seul ou qui a atteint 9 kg (20 lb).

• Ne pas placer, dans cette couchette ou à proximité, de cordon, de courroie ou d'objets semblables susceptibles d'entourer le cou de l'enfant.

• NE PAS placer cette couchette près d'une fenêtre ou d'une porte-fenêtre, là où l'enfant pourrait atteindre le cordon d'un store ou d'un rideau et risquer l'étranglement.

• Vérifier régulièrement cette couchette avant de l'utiliser et ne pas l'utiliser si des pièces sont lâches ou manquantes, ou encore en présence de tout dommage apparent. Ne pas substituer de pièces. Communiquer avec le fabricant pour obtenir des pièces de rechange ou des directives supplémentaires.

• Les bébés peuvent s'étouffer avec de la literie molle. Ne pas placer d'oreillers, de douillettes ni de matelas moelleux dans cette couchette.

• Cette couchette comprend un matelas de 25 mm (1 po). Utiliser uniquement le matelas fourni par le fabricant avec cette couchette. Ne pas ajouter de matelas supplémentaire dans cette couchette.

• Utiliser uniquement la housse de matelas fournie avec ce produit. Ne pas utiliser de drap avec ce matelas.

• TOUJOURS utiliser le matelas.

• Cette couchette convient uniquement à un enfant qui ne peut pas se retourner seul ou qui n'a pas atteint 9 kg (20 lb). Taille maximale de l'enfant : 66 cm (26 po). Tout poids excessif peut occasionner une situation dangereuse d'instabilité.

RISQUE D'ÉTRANGLEMENT :

- Les ficelles et les cordons peuvent causer un étranglement!

• Gardez les ficelles et les cordons hors de la portée des enfants.

• Ne mettez JAMAIS d'objets avec une ficelle autour du cou d'un enfant, comme les cordons de capuche ou de tétine. N'accrochez JAMAIS de ficelles au-dessus

⚠ MISE EN GARDE

d'un produit et n'attachez JAMAIS de ficelles à des jouets.

- Ne pas utiliser le berceau si une pièce quelconque est déchirée, endommagée, cassée ou manquante.
- Ne pas utiliser cette couchette en présence de flammes ouvertes ou d'autres sources de chaleur intense, comme un élément électrique chauffant, une flamme au gaz, etc. à proximité de la couchette.
- Ne pas laisser d'autres enfants jouer sans surveillance à proximité de la couchette.
- Utilisez uniquement des pièces de rechange fournies ou approuvées par le fabricant.
- Le produit peut être utilisé sur la poussette comme couchette et pour transporter un enfant.
- Couchez toujours bébé sur le dos pour dormir afin de réduire les risques de mort subite du nourrisson et d'étouffement.
- S'assurer que les côtés de la couchette sont correctement attachés ou verrouillés dans la position appropriée avant d'y placer un enfant.

DÉBALLAGE

1 Après avoir déballé la couchette, soulever le baldaquin jusqu'à ce qu'il s'enclenche, puis détacher les quatre bandes de fixation situées autour du baldaquin.
2 Retirer ensuite le matelas et détacher les deux bandes de fixation situées autour des supports du baldaquin pour en retirer la doublure.
3 Tirer sur les sangles noires pour faire glisser les barres de réglage métalliques jusqu'à ce qu'elles soient verrouillées contre les butées de la base pour stabiliser les parois du module de la couchette. Remettre la doublure en place et insérer le matelas.

COUVRE-PIEDS

4 Pour fixer le couvre-pieds, il faut l'installer d'abord sur le cadre de la couchette.
5 Fixer les bandes de fixation de chaque côté du module de la couchette.
6 De chaque côté du couvre-pieds, enfiler l'attache dans la boucle et fermer les boutons-pression pour fixer le couvre-pieds au cadre de la couchette.
7 Il est également possible de rabattre le dessus du couvre-pieds et de le fixer à l'aide des boucles inférieures.

BALDAQUIN

8 Soulever le baldaquin jusqu'à ce qu'il s'enclenche en position B. Continuer à soulever le baldaquin jusqu'à la position A en appuyant sur les boutons situés des deux côtés de la charnière du baldaquin.

⚠**MISE EN GARDE :** Avant de le transporter ou de le soulever, s'assurer que le baldaquin est bien enclenché en position A. REMARQUE : Le baldaquin possède 2 positions verrouillées. Pousser et tirer sur la poignée pour s'assurer que le baldaquin est bien verrouillé en place. Le baldaquin peut être installé dans n'importe quelle position lorsqu'il est utilisé dans la poussette.

9 Pour abaisser le baldaquin, appuyer sur les boutons situés des deux côtés de la charnière du baldaquin, puis abaisser le baldaquin.
10 Pour utiliser la fenêtre du baldaquin, détacher la fermeture à glissière du baldaquin. Rouler ensuite le pare-soleil vers le sommet.

MONTAGE DES ADAPTATEURS

11 S'il s'agit d'un modèle City Select 2, passer à l'étape 12. Adaptateurs de support de montage Summit X3. Poussettes Summit X3 : Si le baldaquin est déjà installé, retirez-le en appuyant sur les boutons de dégagement situés des deux côtés de la poussette, en tirant vers le haut. Insérer les adaptateurs dans les supports de montage d'accessoires sur la poussette. REMARQUE : La gauche et la droite sont déterminées en se tenant devant la poussette, face à elle.

ANCRAGE À LA POUSSETTE

12 Aligner les supports de fixation noirs du module de la couchette Deluxe 2 aux supports de fixation situés sur la poussette. **Le module de la couchette peut être installé uniquement en position orientée vers l'arrière.** Appuyer fermement sur la couchette jusqu'à ce qu'un déclic indiquant qu'il est enclenché en place se fasse entendre. Tirer délicatement sur la couchette pour s'assurer qu'elle est solidement fixée en place.
13 Pour détacher le module de la couchette de la poussette : Appuyer sur le bouton de dégagement de chaque support de fixation et tirer vers le haut pour les retirer.

RETRAIT DE LA DOUBLURE DE TISSU

14 Détacher la glissière du baldaquin à partir de la poignée.
15 Détacher les quatre bandes de fixation situées autour du baldaquin et retirer le tissu du baldaquin.
16 Détacher les deux bandes de fixation situées autour des supports du baldaquin de la couchette pour en détacher la doublure.

ENTREPOSAGE

17 Pour replier le module de la couchette pour le ranger : Retirer le matelas et la doublure. Appuyer sur les languettes de dégagement et tirer sur les sangles noires afin de faire glisser les barres de réglage métalliques vers le milieu. Replier pour le rangement.
18 Lors du transport avec un enfant, tenez toujours le landau par les poignées situées sur les côtés du landau.

SOIN ET ENTRETIEN

- Consulter les directives de lavage sur l'étiquette d'entretien :
  - Nettoyer en essuyant avec un linge humide.
  - Laver à la main à l'eau froide avec un détergent doux.
  - Laver à la machine séparément à l'eau froide au cycle délicat.
- N'utiliser aucun agent de blanchiment.
- Ne pas mettre dans la sécheuse.
- Ne pas repasser.
- Ne pas nettoyer à sec.
- Étendre à plat pour sécher.
- Retirer le mousse de matelas avant le lavage de la housse de matelas.

NOTES

NEW ZEALAND ONLY
Baby Jogger's Limited Warranty

Baby Jogger warrants that the frame is free of manufacturer defects for the lifetime of the product. Manufacturer's defects include but are not limited to the breaking of welds and frame tube damage. Textile or soft side materials and all other components shall be warranted for one year from the date of purchase (except for tubes and tires). Proof of purchase is required to make a warranty claim and the warranty is only extended to the original purchaser.

Your stroller comes with a limited lifetime warranty on the frame and a 12 month warranty on textiles and mechanical components. Visit **www.babyjogger.co.nz** to register your new stroller and we'll extend your warranty by a further 12 months.

THIS WARRANTY DOES NOT COVER:

- Normal wear and tear
- Corrosion or rust
- Incorrect assembly, or the installation of third party parts or accessories not compatible with the original design.
- Accidental or intentional damage, abuse or neglect, or use on stairs, travelators or escalators.
- Commercial use
- Improper storage/care of the unit

This warranty specifically excludes claims for indirect, incidental, or consequential damages. The implied warranties of merchantability and fitness for a particular purpose is according to the specific warranty period for this model unit at time of purchase. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. To know what your legal rights are in your state, consult your local or state consumer affairs office or your State's Attorney General.

The benefits given to you by our warranty are in addition to other rights and remedies under law in relation to the product. Our goods also come with guarantees that cannot be excluded under the New Zealand Consumer Guarantees Act. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

NOTE: When contacting Baby Jogger distributor regarding your bassinet, please have your bassinet's model number and manufacturing date ready. It can be found underneath the fabric liner.

IN NEW ZEALAND CONTACT:

Call: 0800.333.006

Mail: Rumina Natural Care Ltd
9 Southgate Place
Henderson, Auckland, 0612
New Zealand


PLEASE DO NOT CONTACT THE PLACE OF PURCHASE FOR PARTS OR WARRANTY ISSUES

Product Registration
Enregistrement du produit

To register your Baby Jogger product from within the U.S.A. visit us online at www.babyjogger.com or return registration card provided with your product. In Canada, visit www.babyjogger.ca to register your product.

Pour inscrire votre produit Baby Jogger aux États-Unis, visiter notre site internet www.babyjogger.com ou retourner la carte d'enregistrement fournie avec le produit. Au Canada, visiter www.babyjogger.ca pour enregistrer votre produit.

GLB



Baby Jogger, LLC
5 Concourse Parkway, 8th Floor • Atlanta, GA 30328
1.800.241.1848 • www.babyjogger.com