Mr. Coffee

PERFECT BREW
QUICK START GUIDE



P/N: NWL0001770576
BVMC-IHCTM08SS

Mr. Coffee

PERFECT BREW
QUICK START GUIDE

BEFORE FIRST USE

WARNING: This quick start guide is not intended to be a substitute for the product manual, and you should read and understand the warnings and instructions in the product manual before using this appliance.

1. Carefully unpack your unit.
   IMPORTANT: REMOVE THE RED PLUG FOUND AT THE BASE OF THE WATER RESERVOIR.
2. Wash Glass Carafe, Coffee and Tea Brew Baskets, Coffee and Tea Reusable Filters, Water Reservoir, and Dual-Sided Scoop.
3. Dry parts thoroughly.
4. Plug into a 120V AC power outlet.
5. Perform cleaning cycle. (See product manual for detailed instructions.)

MAKING HOT COFFEE

1. Fill the Water Reservoir with fresh, filtered cold water no higher than the MAX line.
   NOTE: The unit will dispense the appropriate amount of water based on the selected brew size.
2. Insert the Coffee Brew Basket and Filter.
   NOTE: You may use only one option: either No. 4 Paper or the Reusable Mesh Filter. Using both will cause overflow.
3. Using the Brew Type menu, select HOT by rotating the knob and pressing select.
4. Using the Brew Size menu, select the desired brew size (8 oz, 12 oz, 16 oz or Carafe) by rotating the knob and pressing select.
   NOTE: Warming plate is only active for the 'Carafe' setting size.
5. Using the 'Coffee' side of the Dual-Sided Scoop, add to the Coffee Filter the correct amount of coffee scoops as shown on the display.
   NOTE: Changing the brew size will change the number of scoops needed.
6. Carefully place cup, travel mug, or carafe under the brew spout (depending on your brew size). Ensure cup or travel mug used for single serve have adequate capacity for the selected brew size.
7. Press BREW/CANCEL to start brewing!

CLEANUP & STORAGE

1. Check product manual for detailed directions on how to clean and store your unit.

Mr. Coffee

PERFECT BREW
QUICK START GUIDE

PERFECT BREW TIPS

1. The warming plate is only active for the 'Carafe' brew size. For single-serve sizes like the 8 oz, 12 oz, or 16 oz, brew using an insulated tumbler for best performance.

2. For better coffee and easier brew basket cleanup, use a No. 4 paper filter (available at local supermarkets).

3. To avoid overflow, DO NOT use both the Reusable Mesh Filter and a Paper Filter simultaneously.

4. Before you start brewing, add the appropriate amount of water to the reservoir to avoid the 'ADD WATER' alert.

5. The unit may drip after brewing. Place the carafe back on the warming plate to catch any liquid from the brew spout.

6. The Pause and Serve feature, activated by the intelligent IR sensor when removing the carafe slowly during brewing, will prevent splashes and drips on the warming plate.
   NOTE: This feature is only available for the 'Carafe' brew size.