

NWL0001681392G
6/25



GoMax™
INFANT CAR SEAT

Read This Instruction Manual

Do not install or use this child restraint until you read and understand the instructions in this manual.

**FAILURE TO PROPERLY
USE THIS
CHILD RESTRAINT
INCREASES THE
RISK OF SERIOUS
INJURY OR DEATH IN
A SUDDEN STOP OR
CRASH.**

**KEEP INSTRUCTIONS
FOR FUTURE USE.**

www.gracobaby.com



Important

Pages 4-11

- 1-A Welcome to the Graco Family!**
- 1-B Safety Warnings**
- 1-C Aircraft Installation**

Features

Pages 12-19

- 2-A Car Seat Features**
- 2-B Remove Car Seat from Base**
- 2-C Attach Car Seat to Base**
- 2-D Adjusting Carry Handle**
- 2-E Choosing Vehicle Seat Location**
- 2-F Which Installation Method Should I Use?**

Rear-Facing Use

Pages 20-46

- 3-A Rear-Facing Checklist**
- 3-B Install Without Base With Built-in Rigid Lower Anchor Connectors**
- 3-C Install With Base With Lower Anchor Attachment**
- 3-D Install With Base With Vehicle Seat Belt**
- 3-E Install Without Base With Vehicle Seat Belt**

Securing Child

Pages 47-56

- 4-A Adjust Harness to Fit Child**
- 4-B Adjust Buckle to Fit Child**
- 4-C Securing Child in Car Seat**
- 4-D Removing Child**

Carrier Use

Pages 57-58

Vehicle Information

Pages 59-64

- 6-A How to Remove Built-in Rigid Lower Anchor Connectors**
- 6-B How to Remove Lower Anchor Attachment**
- 6-C Unsafe Vehicle Seats**
- 6-D Vehicle Seat Belts**

Accessories

Page 65

Care & Cleaning

Pages 66-71

- 8-A Cleaning Seat Pad**
- 8-B Cleaning Buckle**
- 8-C Cleaning Harness and Lower Anchor Attachment**



1 Important

1-A Welcome to the Graco Family!

Your child's safety depends on you. **No car seat can guarantee protection from injury in every situation, but proper use helps reduce the risk of serious injury or death.**

READ THIS MANUAL CAREFULLY.

This child restraint system conforms to all applicable Federal motor vehicle safety standards.

Even if this car seat seems easy to figure out on your own, you must follow the detailed instructions in this instruction manual to ensure the steps are performed correctly.

If You Need Help

In the U.S.A, please contact our Customer Service Department with any questions you may have concerning parts, use, or maintenance. When you contact us, please have your product's model number and date of manufacture ready so that we may help you efficiently. These numbers can be found on a sticker on the back side of your car seat.

Contact us at **www.gracobaby.com or call 1-800-345-4109.**

For additional resources or to get your car seat checked by a child passenger safety technician, please visit the following web sites:

www.nhtsa.gov • www.seatcheck.org • www.safekids.org

This car seat is for children 4-30 lb (1.8-13.6 kg) and 32" (81 cm) or less.

Note: Preterm or low birth weight infants may be at special risk in a vehicle or aircraft. According to the AAP, these infants may suffer breathing issues if improperly reclined in a car seat. Use the corrected age for preemies. Graco advises that you have your physician or hospital staff evaluate your infant and recommend the proper car seat or car bed before you and your infant leave the hospital.

Register This Child Restraint

Please fill out the prepaid registration postcard attached to the harness and mail it in today **or register online at www.gracobaby.com/carseatregistration.**

Child restraints could be recalled for safety reasons. You must register this restraint to be reached in a recall. Send your name, address, and the restraint's model number and manufacturing date to:

Graco Children's Products, Inc.
Attn: Customer Service
P.O. Box 169, Elverson, PA 19520-9901
or call 1-800-345-4109
or register online at
www.gracobaby.com/carseatregistration

For recall information, call the U.S. Government's Vehicle Safety Hotline at 1-888-327-4236 (TTY: 1-800-424-9153), or go to <http://www.NHTSA.gov>.



1 Important



1 Important

For future reference or if you change addresses, record the model name, model number, date of manufacture, and purchase date of this car seat below. You can find this information either on the registration card if you still have it or on the date label located on the back of the car seat.

Model Name _____

Model Number _____

Date of Manufacture _____

Date of Purchase _____

1-B Safety Warnings



1 Important

! WARNING!

Failure to follow these instructions and child restraint's labels can result in child striking the vehicle's interior during a sudden stop or crash.

! According to accident statistics, children are safer when properly restrained in the rear seating positions than in the front seating positions. The center of the back



seat can be the safest during a possible side impact.



! NEVER place this child restraint rear-facing in a vehicle seating location that has an active front air bag.

If an air bag inflates, it can hit the child and car seat with great force and cause serious injury or death to your child.

! Review your vehicle owner's manual for more information about air bags and car seat use.

! If your vehicle does not have a back seat, review your vehicle owner's manual.

! Children are safer riding rear-facing and should ride rear-facing as long as possible, until they reach the maximum rear-facing height or weight rating for their car seat. Graco convertible and all-in-one car seats

have higher rear-facing limits that will allow children to ride rear-facing longer after outgrowing their infant car seat. Be sure to check your local and state laws, as well as AAP and NHTSA recommendations, for car seat usage.*

- ! This child restraint must only be used with children weighing between 4-30 lb (1.8-13.6 kg).**
- ! Select a suitable location for the car seat in your vehicle.**
- ! Secure car seat with a vehicle seat belt or lower anchor attachment that is properly routed as shown in this manual.**
- ! Vehicle seat belt system **MUST** hold car seat securely. Not all vehicle seat belts can be used with a car seat.**
- ! If vehicle seat belt does not hold car seat securely, read “Vehicle Seat Belts” section 6-D and your vehicle owner’s manual.**
- ! Always secure car seat with lower anchor attachment or a vehicle seat belt, even when unoccupied. In a crash, an unsecured car seat can injure passengers.**
- ! DO NOT use car seat if it is damaged or missing parts.**

*Graco Supports the American Academy of Pediatrics and National Highway Traffic Safety Administration’s Car Seat Guidelines. Visit www.gracobaby.com/en-US/safety for information on car seat usage recommendations.



1 Important

- ! If car seat is in a crash, it must be replaced. DO NOT use it again! A crash can cause unseen damage and using it again could result in serious injury or death.**
- ! DO NOT use accessories or parts other than those provided by Graco except for a thin towel or mat to protect your vehicle seat or rolled towels or pool noodles to help get your car seat level. Their use could alter the performance of the car seat.**
- ! DO NOT remove lower anchor attachment system from car seat. If using vehicle seat belt to secure car seat, lower anchor attachment connectors must be stored.**
- ! Never leave child unattended, even when sleeping. Child may become tangled in harness straps and suffocate or strangle.**
- ! Rear-facing car seat must be properly leveled:**
 - Too reclined can result in injury or ejection.**
 - Too upright can result in breathing difficulties.**
-  **! Never attach two lower anchor attachment connectors to one vehicle lower anchor point unless specifically allowed by the vehicle manufacturer.**
- ! Do not use both the vehicle seat belt and lower anchor attachment strap at the same time when using the car seat rear-facing.**
- ! NEVER use a Graco infant carrier with any other manufacturer's strollers. This can result in serious injury or death.**



1 Important

Compatibility

Using Graco® strollers with product

To avoid injury to your child: this product is compatible with most Graco® Strollers. For additional questions or for more information on compatibility please call Graco's customer service number:

1-800-345-4109 or scan below for compatibility:



Car Seat's Useful Life

STOP using this car seat and throw it away 7 years after the date of manufacture. Look for date of manufacture label on back of the car seat.

Graco Children's Products Inc. advises against loaning or passing along a car seat unless you know the complete history of the product. We also advise against purchasing a car seat second hand.

Warm Weather Use

Car seat parts can get very hot in the sun or warm weather. **To avoid burns, always check before putting child in car seat.**


1-C Aircraft Installation



1 Important



This child restraint is certified for use in aircraft when used without the base. Use only on forward-facing aircraft seats. Follow the instructions for vehicle installation. See sections 3-D and 6-D Lap Belt Installation.




This child restraint's **base** is NOT certified for use in aircraft.


Contact the airline for their specific policies.

When installing the car seat, route the lap seat belt through the proper path and buckle it in. Then, pull on the tail of the belt so that the lap belt gets tight around the car seat.

Grab the sides of the seat at the belt path where the lap belt is and move the car seat from side-to-side and front-to-back. If it moves less than 1" (2.5 cm), it is tight enough.




2-A Car Seat Features




- A** Carry Handle
- B** Canopy
- C** Headrest Adjustment Lever
- D** Headrest
- E** Handle Adjustment Button
- F** Rear-Facing Belt Path
(When Used Without Built-in Rigid
Lower Anchor Connectors)



- G** Harness
- H** Level Indicator
- I** Harness Release Lever
(Under Pad)
- J** Harness Adjustment
Strap
- K** Removable Base




- L** Car Seat Shell
- M** Release Lever
- N** Harness Covers
- O** Harness Straps
- P** Chest Clip
- Q** Buckle Tongues
- R** Buckle
- S** Buckle Strap




2 Features




- A Release Lever**
- B Harness Straps**
- C Buckle Metal Clip**
- D Built-in Rigid Lower Anchor Connectors**
- E Recline Adjustment Lever**
- F Rear-Facing Belt Path**
(When Used Without Base)



- G* Car Seat Base Lock**
- H* Level Line**
- I* SnugLock® Lock-Off**
- J* SnugLock® Lock-Off Release Lever**
- K* Lower Anchor Attachment Storage**
- L* Base Recline Lever**
- M* Base Recline Foot**




2-B Remove Car Seat from Base



To Remove Car Seat from Base


From the back of the car seat, squeeze the release lever and lift the car seat out of the base.

2-C Attach Car Seat to Base



Attaching Car Seat To Base

Align the locking bar at the front and rear of the car seat with the locks in the base. Set car seat in the base. Push down on the the car seat. You will hear a “click” when it is locked.



Pull up on the front and rear corners of the seat to make sure it is locked.

2-D Adjusting Carry Handle


1. To Rotate Handle

Press the handle adjustment buttons on both sides of handle. **MAKE SURE** handle locks into position before lifting the carrier.



2. Handle Has 4 Positions

Rotate handle to any of the 4 locked positions. Push and pull the handle to make sure handle is in a lock position. Carry handle **MUST** be upright in position A when carrying. Handle can be in any position when used in the vehicle.



2 Features

2-E Choosing Vehicle Seat Location

Review your vehicle owner's manual for seating locations. Review section 6 for additional information.

Some vehicles have specific requirements for where the car seat can be installed. Be sure to check your vehicle owner's manual for all available seating positions.

WARNING!



NEVER place this child restraint rear-facing in a vehicle seating location that has an active front air bag.


In the event there is no back seat, review your vehicle owner's manual to see how to use your infant child restraint.

2-F Which Installation Method Should I Use?

This car seat can be installed in your vehicle using either the vehicle seat belt OR the lower anchor attachment system. Both systems are equally safe to use. **DO NOT USE BOTH AT THE SAME TIME.**

The lower anchor attachment system allows you to securely attach your car seat in your car without using the vehicle seat belt and possibly to get a better fit. All 2003 and newer model year vehicles are required to have a lower anchor attachment system, although some manufacturers began including lower anchor attachment earlier. Some vehicle owner manuals use the term ISOFIX to identify the lower anchor attachment system.


Review your vehicle's owner manual for exact location and use. Review section 6 for additional information.




Vehicle Seat Crease

Typical seat in a passenger vehicle.
Other vehicle types may have different
lower anchor attachment locations.


**Vehicle Lower
Anchor**




3-A Rear-Facing Checklist



Built-In Rigid Lower Anchor Connectors



Lower Anchor Attachment



Vehicle Lap/Shoulder Seat Belt

**Rear-Facing:
4-30 lb (1.8-
13.6 kg) 32"
(81 cm) or less**



- Car seat **MUST** be rear-facing in the vehicle back seat.
- Make sure lower anchor attachment strap or vehicle seat belt is routed through the rear-facing belt path, marked with a blue label.
- Install this car seat tightly in your vehicle. When installed with the Lower Anchor Attachment or the vehicle seat belt, the car seat **should not move** at the belt path more than 1" (2.5 cm) from side to side and front to back.
- Make sure to check the level indicator or level line for proper recline.
- Harness straps must be **at or just below** the top of child's shoulders and chest clip must be at **armpit level**.



**3 Rear
Facing**


- Make sure base is a minimum of 80% on vehicle seat.

Children are safer riding rear-facing and should ride rear-facing as long as possible, until they reach the maximum rear-facing height or weight rating for their car seat. Graco convertible and all-in-one car seats have higher rear-facing limits that will allow children to ride rear-facing longer after outgrowing their infant car seat. Be sure to check your local and state laws, as well as AAP and NHTSA recommendations, for car seat usage.


⚠ WARNING!




NEVER
place this
child
restraint
rear-facing in a
vehicle seating
location that has an
active front air bag.



Vehicle Lap Only Seat Belt




***Vehicle Lap/Shoulder
Seat Belt Without Base***



***Vehicle Lap Only Seat Belt
Without Base***



3-B Install Without Base With Built-In Rigid Lower Anchor Connectors




1. Rotate the Built-In Rigid Lower Anchor Connectors

On the front of the car seat, pull down on the Built-In Rigid Lower Anchor Connectors until you hear a "Click!".

Note: The Built-In Rigid Lower Anchor Connectors will always rotate into the previous recline position selected.

2. Place Car Seat in Back Seat of the Vehicle

Place the car seat on the vehicle seat.






**3 Rear
Facing**

3. *Attach the Built-In Rigid Lower Anchor Connectors to Vehicle's Lower Anchors*

Slide the car seat into the vehicle seat back and attach the Built-In Rigid Lower Anchor Connectors to vehicle's lower anchors.


The Built-In Rigid Lower Anchor Connectors can only be used if the vehicle lower anchor spacing is 11 inches (28 cm) from the center of one lower anchor to the center of the other lower anchor.



**3 Rear
Facing**



3 Rear
Facing



4. *Check the Lock Indicator*

Check the lock indicator on both rigid lower anchor connectors.

If the indicator is red, the car seat is **NOT** secure.

The car seat is secure when **BOTH** indicators show green.

5. Check the Level Indicator



Vehicle **MUST** be on level ground.

- Place the bubble completely within the blue lines to ensure the seat is level.



- For a more reclined position place the bubble in the light blue line.

- For more upright seating, the bubble can be partially or completely in the dark blue line.

- If the bubble is not completely under the blue lines, the child restraint is NOT level. You must adjust your recline position.



3 Rear
Facing



Note: In some vehicles the car seat may fit too tightly to easily adjust the recline. If so, disconnect the car seat from the vehicle then pull down the Built-In Rigid Lower Anchor Connectors and adjust the recline before connecting the Built-In Rigid Lower Anchor Connectors to the vehicle.

6. Recline the Car Seat

If the bubble in the level indicator is not under the correct line for your child's age, you must adjust the recline position.

To adjust the recline, squeeze the recline lever on the left side of the car seat and rock the seat up or down to one of the four recline positions. Recheck the level indicator.

Note: The Built-In Rigid Lower Anchor Connectors will always rotate into the previous recline position selected.

Recheck the level indicator with child in the child restraint.

Note: If the Built-In Rigid Lower Anchor Connectors are in the lowered position and you would like to store them, simply squeeze the release lever on the back of the car seat. Review section 6-A for additional information


3-C Install With Base With Lower Anchor Attachment

Review your vehicle owner's manual for lower anchor attachment location and use.


1. Place Base in Back Seat of the Vehicle

Place the base flat on the vehicle seat. Push it back until the front of the base touches the vehicle seat back. Center the base between the lower anchor attachment anchors.

If allowed by your Vehicle Owner's Manual, the center seating position may be used if the anchor spacing is 11" (28 cm) or greater.




3 Rear Facing




**2. Remove the
Lower Anchor
Attachment
Connectors
from Storage
Location**

Unhook the lower anchor attachment connectors and remove from storage position.




**3. Open the SnugLock®
Lock-Off**

Push in the release lever and open the lock-off.



4. Extend the Lower Anchor Attachment Strap

Extend the lower anchor attachment strap to its maximum length by pressing the gray button and pulling on the strap.




5. Check the Level Line


The red level line on the side of the base **MUST BE LEVEL** with the ground.

Once the seat is installed, make sure the bubble on the level indicator is completely within the blue lines.

Readjust the recline if needed.



**3 Rear
Facing**




6. Recline the base

If the red level line is not level with the ground, you **MUST** adjust the recline position.

To adjust the recline, squeeze the base recline lever on the front of the base and lift or lower the base to the appropriate recline.

Recheck the level line.


When the foot is completely extended and the level line is not level to the ground, you may raise the foot and place a rolled towel or pool noodle under the foot until the line is level to the ground.



3 Rear
Facing

7. Connect Lower Anchor Attachment Connectors to Vehicle's Lower Anchor Attachment Anchors


Lower anchor attachment strap should lay as flat as possible and not be twisted.



8. Remove the Slack

Press down firmly on the top of the base while pulling on the free end of the lower anchor attachment strap to remove all the slack.


Do not pull on the strap with excessive force.



**3 Rear
Facing**



**3 Rear
Facing**




9. Close the SnugLock® Lock-Off

Shut the lock-off on top of the lower anchor attachment strap.

Close the lock-off until you hear a “Click”.

! WARNING!

Keep hands away from the lock-off area when closing the lock-off.




10. Test For Tightness

Grab the sides of the base at the belt path, push and pull the base from side to side and front to back.


If the base moves less than 1” (2.5 cm), it is tight enough.

11. Attach Car Seat to Base




Place car seat into the base. Push down on the front and rear of the car seat and handle until you hear a “click”.



Test to make sure the car seat is attached by pulling up on the front and rear corners of car seat.



**3 Rear
Facing**



12. Check the Level Indicator

Vehicle **MUST** be on level ground.

Check the level indicator with child in the child restraint.

- Place the bubble completely within the blue lines to ensure the seat is level.

- For a more reclined position place the bubble in the light blue line.


- For more upright seating, the bubble can be partially or completely in the dark blue line.

- If the bubble is not completely under the blue lines, the child restraint is **NOT** level. You must adjust your recline position.

3-D Install With Base With Vehicle Seat Belt


1. Store Lower Anchor Attachment Connectors

Attach the lower anchor attachment connectors to the plastic bars on sides of base as shown. Remove the slack.



2. Place Base in Back Seat of the Vehicle




Place the base flat on the vehicle seat. Push it back until the front of the base touches the vehicle seat back.



3 Rear
Facing



3 Rear
Facing



3. *Open the SnugLock® Lock-Off*

Push in the release lever and open the lock-off.

4. *Check the Level Line*

The red level line on the side of the base **MUST BE LEVEL** with the ground.

Once the seat is installed, make sure the bubble on the level indicator is completely within the blue lines.

Readjust the recline if needed.



5. Recline the base

If the red level line is not level with the ground, you **MUST** adjust the recline position.



To adjust the recline, squeeze the base recline lever on the front of the base and lift or lower the base to the appropriate recline.

Recheck the level line.


When the foot is completely extended and the level line is not level to the ground, you may raise the foot and place a rolled towel or pool noodle under the foot until the line is level to the ground.



3 Rear
Facing



Review your vehicle's owner's manual for vehicle seat belt use



6. Route the Vehicle Seat Belt

Thread the vehicle seat belt through the rear-facing belt path (marked with a blue label) and buckle it. The seat belt should lay as flat as possible and not be twisted.


7. Tighten the Vehicle Seat Belt

Press down firmly on the top of the base while pulling on the shoulder belt to remove the slack.

Do not pull on the strap with excessive force.

**8. Close the SnugLock®
Lock-Off**

Push down on the
arm until the you hear
a click.






! WARNING!

**Keep hands away from the lock-off area when
closing the lock-off.**



**3 Rear
Facing**



9. Test For Tightness

Grab the sides of the base where the seat belt is and push and pull the base from side to side and front to back.

If the base moves less than 1" (2.5 cm), it is tight enough.

10. Attach Car Seat to Base

Place car seat into the base. Push down on the front and rear of the car seat and handle until you hear a "click".

Test to make sure the car seat is attached by pulling up on the front and rear corners of car seat.

11. Check the Level Indicator

Vehicle **MUST** be on level ground.


Check the level indicator with child in the child restraint.

- Place the bubble completely within the blue lines to ensure the seat is level.

- For a more reclined position place the bubble in the light blue line.

- For more upright seating, the bubble can be partially or completely in the dark blue line.

- If the bubble is not completely under the blue lines, the child restraint is NOT level. You must adjust your recline position.



Reclined




Upright




3 Rear
Facing

3-E Install Without Base With Vehicle Seat Belt



1. *Place Car Seat in Back Seat of the Vehicle*

Place the car seat on the vehicle seat. Push it back until the front of the car seat touches the vehicle seat back.



2. *Check the Level Indicator*

Vehicle **MUST** be on level ground.



3 Rear
Facing



- Place the bubble completely within the blue lines to ensure the seat is level.

- For a more reclined position place the bubble in the light blue line.

- For more upright seating, the bubble can be partially or completely in the dark blue line.


- If the bubble is not completely under the blue lines, the child restraint is NOT level. You must adjust your recline position.

If needed, rolled towels may be placed under the base, at the vehicle seat crease, until the level line is level with the ground.






3 Rear
Facing



3. **Route the Vehicle Seat Belt**

Thread vehicle seat belt through the rear-facing belt path (marked with a blue label) and buckle it. The seat belt should not be twisted.




4. **Lock the Vehicle Seat Belt**

In most vehicles today, **slowly pull the shoulder belt all the way out** and then let it go back in. You will hear a “clicking” sound. Slowly pull out on the belt and it should be locked. If not, review your car’s owner manual and section 6-D.

5. *Tighten the Vehicle Seat Belt*


Lay your forearm across the car seat **at the belt path and push down**. Pull on the shoulder belt to tighten while feeding the slack back in the retractor.





6. *Test For Tightness*

Grab the sides of the car seat where the seat belt is and push and pull the car seat from side to side and front to back.

If the car seat moves less than 1" (2.5 cm), it is tight enough.



3 Rear
Facing



7. Check the Level Indicator

Vehicle **MUST** be on level ground.

Check the level indicator with child in the child restraint.

- Place the bubble completely within the blue lines to ensure the seat is level.

- For a more reclined position place the bubble in the light blue line.

- For more upright seating, the bubble can be partially or completely in the dark blue line.

- If the bubble is not completely under the blue lines, the child restraint is **NOT** level. You must adjust your recline position.


4-A Adjust Harness to Fit Child



4 Securing Child


1. Loosen Harness Straps

Push the harness release button (under seat pad) while pulling out on the harness straps at the chest clip.




2. Release the Chest Clip

Squeeze the chest clip release buttons and pull apart.





4 Securing Child



3. **Unbuckle the Buckle**


Press the red button and pull buckle tongues out. Place harness straps off to the sides.

4. **Place Your Child in the Seat**

Make sure their back is flat against the car seat back.

! WARNING!

WARNING! In cold weather, do not put snowsuits or bulky garments on your child when placing them in the car seat. Bulky clothing can prevent the harness straps from being tightened properly. To keep child warm, buckle your child in the car seat and place a blanket around the child or place the child's coat on backwards after buckling in.



5. **Place Harness Straps Over Child's Shoulders**




6. Check Harness Height

Harness Straps
**MUST BE AT OR
JUST BELOW** the
Child's Shoulders

7. Top of Head **MUST BE AT LEAST 1"** (2.5 cm) **BELOW** the Top of the Car Seat

To Change Harness Height:


Remove child from
child restraint and
loosen the harness
straps.




**4 Securing
Child**



4 Securing Child



Squeeze the headrest adjustment button as shown.



Move the headrest up or down to the proper harness height position.



For smaller babies, shorten headrest by placing the bottom of the flap under the support as shown.




4 Securing Child

4-B Adjust Buckle to Fit Child


1. *Check the Buckle Position*

The correct slot is the one that is closest to your child without being underneath them.




2. *To Change Buckle Position*

Remove child from the seat. From the bottom of car seat, insert the buckle's metal clip up through shell and pad.







From the front, pull buckle out of the pad and shell.





4 Securing Child



3. Insert Metal Clip Into New Location

Push metal clip down through the pad and shell. Make sure the buckle's red button is facing out.

4. Pull Up On Buckle To Check It Is Secured

Make sure buckle's metal clip is completely through pad and shell.

To Shorten Buckle for Low Birth Weight Infants:

(Minimum weight is 4 lb (1.8 kg)):

When crotch strap clip is in rear crotch slot, insert clip into front crotch slot in seat but not through seat pad.


Crotch strap clip should remain flat against seat.

4-C Securing Child in Car Seat




4 Securing Child

1. *Place Harness Straps Over Child's Shoulders*




2. *Buckle*

You will hear a “click” when buckle tongues are securely attached. Pull up on each buckle tongue to make sure it is securely attached.




3. *Buckle the Chest Clip*

You will hear a “click” when the chest clip is securely buckled attached.






4 Securing Child




4. Pull All the Slack Out From Around the Waist

Pull up on the harness strap while pushing the chest clip down. Do this to both sides.



5. Tighten the Harness by Pulling the Adjustment Strap

When you are not able to pinch any of the harness webbing at your child's shoulder, the harness is tight enough.





A snug harness should not allow any slack. It lies in a relatively straight line without sagging. It does not press on the child's flesh or push the child's body into an unnatural position.

**6. Raise the Chest
Clip to Child's
Armpit Level**

7. Check Tightness

Tighten more if needed.




**4 Securing
Child**




4 Securing Child

4-D Removing Child




1. Loosen Harness Straps

Push down on the harness release lever under the seat pad while pulling out on the harness straps at the chest clip.



2. Release the Chest Clip

Squeeze the chest clip release buttons and pull apart.



3. Unbuckle Your Child

Press in on the red button and remove the buckle tongues. Remove Child from the seat.

5-A Carrier Use

WARNING!

Read all instructions before use of the infant carrier. Keep instructions for future use. Do not use the infant carrier if it is damaged or broken.

NEVER leave child unattended. Always stay within arms reach of carrier.

SUFFOCATION HAZARD: Infant carrier can roll over on soft surfaces and suffocate child. **NEVER** place carrier on beds, sofas, or other soft surfaces.

STRANGULATION HAZARD: Children have **STRANGLED** in loose or partially buckled harness straps. Fully restrain the child even when carrier is used outside the vehicle.

FALL HAZARD: Child's movements can move carrier. **NEVER** place carrier on counter tops, tables or any other elevated surfaces.

KEEP STRINGS AND CORDS AWAY FROM CHILD. Strings and cords can cause strangulation. **DO NOT** place carrier near windows where cords from blinds or drapes can strangle a child. **DO NOT** hang strings on or over the carrier. **DO NOT** attach strings to toys.



5
Carrier
Use

! WARNING!

Fall Hazard:

The carrier can fall from a shopping cart. Do not use on a shopping cart.






6-A How to Remove Built-In Rigid Lower Anchor Connectors

To Remove Car Seat from Vehicle

From the back of the car seat, squeeze the release lever then pull the car seat away from the vehicle seat back.


Note: If the Built-In Rigid Lower Anchor Connectors are in the lowered position and you would like to store them, simply squeeze the release lever on the back of the car seat.




! WARNING!

Keep hands away from the Built-In Rigid Lower Anchor Connectors when using the release lever.


6-B How to Remove Lower Anchor Attachment



1. Push Button In While Pulling on Lower Anchor Attachment Strap to Loosen



2. Press the Lower Anchor Attachment Release Button



3. Pull Away From Anchor Point

6-C Unsafe Vehicle Seats

Never install this car seat in side-facing or rear-facing vehicle seats.



6-D Vehicle Seat Belts

Review your vehicle owner's manual for vehicle seat belt use

This car seat can be installed using a vehicle seat belt. To do this, you will need to change the seat belt to a locked mode for use with car seats. With some vehicle seat belts, this is done with the latch plate; with other vehicle seat belts, this is done with the retractor.

Vehicle Seat Belt Terms

Retractor


A device that winds up the unused vehicle seat belt. It is often hidden inside the panels on the walls of the vehicle or in the vehicle seat back.

Latch Plate

The male end of the seat belt with the silver tongue.


Seat Crease

The crease where the vehicle seat back and seat bottom meet.




Identify Your Seat Belt Type

There are two different types of vehicle seat belts that can be used with this car seat:



Lap/Shoulder Seat Belt

3 connection points.



Lap Only Seat Belt

2 connection points.

The following types of vehicle seat belts **CANNOT** be used safely with this car seat:




Lap Belt with Motorized Shoulder Belt



Lap Belt or Shoulder Belt Mounted on Door

Belts Forward of the Seat Crease




Some vehicles you may not get a secure fit. Read both your vehicle and car seat manuals.

Lap/Shoulder Seat Belt Installation

Always review your vehicle owner's manual for specific information about your vehicle seat belts.

Most vehicles manufactured after 1996 will have Switchable retractors in the back seat. If you have any questions about your retractor type, consult your vehicle owner's manual, call Graco or visit www.gracobaby.com/vehicle-seatbelt-information.

To verify you have a Switchable retractor, **slowly** pull the belt all the way out, and then allow it to retract several inches. Try to pull the belt all the way out again. If it cannot be pulled out, it is **Switchable** retractor. Follow the steps in the rear-facing sections in this manual.




7-A Accessories (on select models)

!WARNING!

**To prevent ejection in sudden stop or crash:
The body support can ONLY be used for infants 12 lb
(5 kg) or less.**


Body Support

To remove, pull the body support out from behind the harness straps.




Harness Covers


Make sure that harness covers do not interfere with the placement of the chest clip at armpit level.



If your model does not include a body support, you can use a rolled towel as shown.



8-A Cleaning Seat Pad





1. **Remove Canopy**

Move the canopy fabric aside to reveal the canopy arm.

Push the release button on the canopy arm while pulling on the canopy to remove.


Repeat on the other side.




Undo the 4 fastening strips under the rear of the canopy.

2. Headrest Pad

Move the headrest flap aside and undo the elastic loops on each side of the headrest.




Pull out from around harness straps and pull pad up and away from the headrest.




3. Seat Pad Snaps

Unfasten the 4 snaps on the seat pad.




**8 Care
& Cleaning**



8 Care & Cleaning



Undo the slide latch near each belt path by pulling the seat pad fabric down and away.




Pull out the 3 pins from around the back of the car seat shell.




Carefully pull the pad out from around the level indicator, then off the shell.

4. Inside Tab

on each side underneath the seat pad, slide the thin tab out from between the seat foam and seat shell.



5. Pull Pad Off Shell






Machine wash pad and canopy in cold water with gentle soap on delicate cycle and drip-dry. DO NOT USE BLEACH.

Reverse the steps to reattach the pad to the shell. Make sure harness straps are not twisted.

**8 Care
& Cleaning**

8-B Cleaning Buckle



Remove Buckle to Clean

From the bottom of car seat, insert the buckle's metal clip up through shell and pad. From the front, pull buckle out of the pad and shell.

To clean, place in a cup of warm water and gently agitate the buckle. Press the red button several times while in the water.

DO NOT SUBMERGE THE BUCKLE STRAP. DO NOT USE SOAPS, HOUSEHOLD DETERGENTS or LUBRICANTS.

Shake out excess water and allow to air dry.

Repeat steps as needed until it fastens with a click. Re-insert the buckle into the same slot it was removed. Pull up on crotch buckle to make sure it is secured.

WARNING! Inspect and clean buckle from time to time to remove any objects or debris that could prevent latching.

8-C Cleaning Harness and Lower Anchor Attachment

Surface wash only with mild soap and damp cloth. **DO NOT IMMERSE THE HARNESS STRAPS or LOWER ANCHOR ATTACHMENT STRAP IN WATER.** Doing so may weaken the straps.

If harness straps or lower anchor attachment strap are frayed or heavily soiled, contact Customer Service at www.gracobaby.com or 1-800-345-4109.



Replacement Parts

To purchase parts or accessories in the United States,
please contact us at the following:

www.gracobaby.com

or

1-800-345-4109



Store the instruction manual in the storage pocket under the seat pad on the left side of the seat. The location is marked with the instruction book icon.

