Canon

Use Your Windows® PC To Operate The MFP With
Canon Remote Operation Viewer
Helping To Minimize Touch-Points

Canon Remote Operation Viewer

Operate your imageRUNNER ADVANCE and imagePRESS Lite device from the convenience of your own Windows PC

Get it **FREE** at usa.canon.com.

Limit device contact by using the Canon Remote Operation Viewer from your PC.

- Copy
- Scan and Send
- Fax
- Works with Authentication
- And More!

Use for **remote trainings**, **presentations**, and **demos**.

Manage the device remotely and help **troubleshoot** device issues.

- Change Device Settings
- View Status and Monitor Consumables
- Look Up Device Counters
- And More!

Get started with Canon Remote Operation Viewer

1 Head to **usa.canon.com**.

2 Choose an imageRUNNER ADVANCE or imagePRESS Lite product and click "**Get Product Support.**"

GET PRODUCT SUPPORT

3 Download and install Remote Operation Viewer from the "**Software**" tab in the "**Drivers & Downloads**" section.

Drivers & Downloads

Software

4 Once installed on your PC, open **Remote Operation Viewer**.

Canon Remote Operation Viewer

5 Enter **IP address of the MFP**.

Connect To

Enter the IP address (IPv4/IPv6) or domain name of the device to operate.

Address: XX.XX.XX.XXX

OK   Cancel

6 Now **operate the MFP** as if you were standing in front of it!

Note: Document assumes the Remote Operation Viewer and MFP are on the same network and that the remote operation feature has been activated by an administrator. For information on how to activate the remote operation capability within the imageRUNNER ADVANCE or imagePRESS Lite settings, see the device eManual. Only one remote connection can access an MFP at a single time. Operation Viewer operates in the following system environments only: Windows 7 (32-bit or 64-bit)/Windows 8 (32-bit or 64-bit)/Windows 8.1 (32-bit or 64-bit)/Windows 10 (32-bit or 64-bit)/Windows Server 2008 (32-bit and 64-bit)/Windows Server 2012 (64-bit)/Windows Server 2016 (64-bit).

USA.CANON.COM/SIMPLYADVANCED

Canon