

DO NOT PRINT THIS PAGE

Printing Notes:

Material: 20 Pound (US) or 80 GSM (International) bond paper, white

Ink: Black

Resolution: 150 DPI or above

Printing method: Offset Printing


Binding: Saddle Stitch

Folded size: 4 x 8.5 in (W x H)

*This drawing contains proprietary information and trade secrets of The Coleman Company, Inc.
Unauthorized use or copying is prohibited.*


METRIC (INCH)							
CRITICAL DIMENSION							
CHECKING IS COMPULSORY							
VOLUME	cm ³	01	17-SEP-12	NEW	Christine Z	20024468	
MASS	grams	REV	DATE	MODIFICATIONS	NAME	EDN NO.	
DENSITY	g/cm ³	MATERIAL: SEE NOTES			The Coleman Company, Inc. Wichita, Kansas USA 67219		
GENERAL TOLERANCES EXCEPT AS NOTED		FINISH SPEC.: SEE NOTES			COMPOSITE- NO	SHEET 1 OF 1	
0 TO	6mm	= ±0.1	SCALE:	DATE:	DRAWN BY:	APPROVED BY:	REVISION:
>6 TO	30mm	= ±0.2	1:1	17-SEP-12	Christine Z	SH	01
>30 TO	80mm	= ±0.3	NAME:		PART NO.:		
>80 TO	180mm	= ±0.4	Instruction, Clmn 120 VAC Pump, Eng		4010022046		
>180mm		= ±0.5	ANGULAR		= ± 3°		

Deflation



1. Remove adapter nozzle from inflation end and attach to deflation side of pump. Repeat same steps as inflation. This will draw the air out quickly.

Inflating Standard Pinch Valve



- Attach pinch valve adapter to inflation end of pump.
- Insert pinch valve adapter into pinch valve.
- **Make sure tip of adapter is extended past inner "Flap" inside of valve.** Turn pump on.
- When fully inflated, remove pump from valve and seal valve.

Other Valves

This pump is compatible with most valves on inflatable products. If you have an inflatable product with a valve other than those described above, rotate the adapter sleeve until nozzle end fits valve.



How to Use and Enjoy Your Coleman®

120V QuickPump™ Unit





For products purchased in the United States:

The Coleman Company, Inc.
3600 North Hydraulic
Wichita, KS 67219 U.S.A.
1-800-835-3278 TDD: 1-316-832-8707

For products purchased in Canada:

Sunbeam Corporation (Canada) Limited
DBA Jarden Consumer Solutions
20B Hereford Street
Brampton, ON L6Y 0M1
1-800-387-6161

www.coleman.com

© 2012 The Coleman Company, Inc. All rights reserved.
Coleman®,  and  are registered trademarks and
QuickPump™ and Double Lock™ are trademarks of The Coleman Company, Inc.
The Coleman Company, Inc., a Jarden Corporation company.

Things You Should Know

- Carefully inspect the pump for damage before first use and every use thereafter. Do not use if found damaged.
- Do not change the plug in any way.
- Power supply must be 120 volt AC.
- Keep unit out of reach of children.
- Do not expose to rain or sunlight. Household use only.
- This pump is a high-volume, low-pressure pump. It is intended to inflate items requiring low pressure (such as inflatable beds, inflatable rafts, air mattresses, etc.).
- For fast inflation and maximum motor cooling, always use the largest size nozzle possible.
- **Caution** - Risk of fire and electric shock! Do not operate for more than 15 minutes. Allow 15 minutes off between each operation.

Note: Pump will not work on stem valves or needle valves commonly used on bike tires, basketballs, etc.

Warnings

- Follow the instructions carefully on articles to be inflated, never exceed recommended pressure. Bursting items can cause serious injury.
- Do not open case, electrical hazards may result. There are no user serviceable parts.
- To reduce the risk of fire for electric shock, do not use this pump with any solid-state speed control device.
- Do not use under wet conditions. Keep away from water.
- Never look into or point any opening toward your eyes while pump is operating.
- Do not attempt to put any objects into the inflation or deflation port at any time.
- Never leave pump unattended while in use.
- Do not leave pump connected to the power supply when not in use.
- Never twist the cord.
- Never allow sand, paper, debris or small articles to be sucked into pump while operating.
- Let pump cool before storing the pump inside the box after use.
- Allow pump to cool for 15 minutes after each 15 minutes of continuous operation.

DO NOT EXCEED 15 MINUTES OF CONTINUOUS OPERATION. ALLOW 15 MINUTES OFF BETWEEN EACH OPERATION.

CAUTION: Do not block the air portals during operation, this could damage the motor.

Important Safety Instructions


- **READ AND SAVE THESE INSTRUCTIONS.**
- This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician.
- Do not attempt to defeat this safety feature.
- Unplug or disconnect the appliance from the power supply before servicing.

Warnings

- Do not operate any pump with a damaged cord or plug. Discard pump or return to an authorized service facility for examination and/or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area where it will not be tripped over.

Grounding Instructions (If Applicable)

This pump should be grounded while in use to protect the operator from electric shock. The pump is equipped with a 3-conductor cord and 3-prong grounding type plug to fit the proper grounding type receptacle. The green (or green and yellow) conductor in the cord is the grounding wire. Never connect the green (or green and yellow) wire to a live terminal. This pump is for use on less than 150V, and has a plug that looks like that shown in sketch (A). An adapter, see sketch (B), is available for connecting sketch (A) type plugs to 2-prong receptacles. The green colored rigid ear, lug, or the like, extending from the adapter must be connected to a permanent ground, such as a properly grounded outlet box. (See Fig. 1)




Extension Cords


Make sure your extension cord is in good condition. When using an extension cord, be sure to use one heavy enough to carry the current your product will draw. An undersized cord will cause a drop in the line voltage resulting in loss of power and overheating. The following table shows the correct size to use depending on cord length and nameplate ampere rating. If in doubt, use the next heavier gauge. The smaller the gauge number, the heavier the cord.

Volts 120V	Total length of cord in feet			
	0-25'	26'-50'	51'-100'	101'-150'
Ampere rating More Than - Not More Than	AWG			
0-6	18	16	16	14
5-10	18	16	14	12
10-12	16	16	14	12
12-16	14	12	Not recommended	

Inflating Coleman® Double Lock™ Valve




1. To begin inflation, open external cap and pull firmly on the lanyard to extend out. This will open internal yellow seal.





2. Attach adapter nozzle to inflation end of pump. Insert pump and turn on.

Note: The pump may look different from yours. It is for illustration purposes only.



3. When fully inflated, seal valve by pushing in with pump nozzle. This will seal the internal yellow stopper and keep air from escaping while closing cap. Gently twist adapter sleeve to right while backing pump out of valve.



4. Fully remove pump and close external cap. Valve should appear depressed into itself.

