



DOOR DETAIL



TRIM DETAIL

(RENT FUNCTION ILLUSTRATED)



NOTE:

- 1) WHEN PREPARING DOOR FOR L_{DBL} FUNCTION, OMIT DRILLING OF Ø.625 TURN KNOB HOLE (INSIDE). DRILL A Ø 1.250 CYLINDER HOLE INSTEAD, USING SAME CENTER LINE AS OUTSIDE CYLINDER HOLE.
- 2) FOR ADDITIONAL LOCK AND DOOR CUTOUT DIMENSIONS, SEE APPROPRIATE LOCK TEMPLATE.
- 3) DRILL ALL HOLES HALF WAY THROUGH DOOR UNLESS OTHERWISE SPECIFIED.
- 4) INSTALLATION PLATES ARE NOT REQUIRED FOR THIS TRIM.

 BALDWIN HARDWARE CORPORATION READING, PENNSYLVANIA	BLACK & DECKER COMPANY	
		6976 MINNEAPOLIS TRIM
TEMPLATE: NO VARIATIONS		TEMPLATE NO.
©2006 BY BALDWIN HARDWARE CORPORATION		1-976

DO NOT SCALE DRAWING

EFFECTIVE 01/01/07